

Part Number: BMW-R18-SB

Description: Sissy Bar

Fitment: 2021 BMW R 18

Revision: 1

Corbin

Tools Required	Parts List
T-40 Torx Wrench 5mm Allen Wrench Loctite®	1 #BMW-R18-SB Sissy Bar Rack 4 #SP00973 8m x 40m x 1.25 Cap Allen Bolts 4 #SP00109 5/16" Flat Washers

NOTE: It would be helpful to have a second set of hands during this installation to help hold some of the parts in position while installing the sissy bar.

1. Start by removing the 4 torx bolts on the rear fender using a T-40 torx wrench (*Figure 1*).

NOTE: Discard bolts, but reuse the plastic rings and aluminum spacers (*Figure 2*).

2. Tape the plastic rings and aluminum spacers onto the fender where you removed the bolts (*Figure 3*). This will help keep the plastic rings and spacers in place while installing the sissy bar.

3. Install the sissy bar by putting it in place (*Figure 4*), lift up the fender to align the holes on the bracket to the holes on the fender, then secure with the supplied 8m x 40m x 1.25 cap Allen bolts and 5/16" flat washers (*Figure 5*), using a 5mm Allen wrench (*Figure 6*).

NOTE: Start all 4 bolts, remove the tape, then tighten the bolts. Use Loctite®



FIG 1



FIG 2



Questions? Give us a holler...
800-223-4332
tech@corbin.com