

**Part Number:** Z-SRS-20-TAIL

**Description:** Rear Fender / Undertail kit

**Fitment:** 2020 Zero SR/S

**Revision:** 1



Tools Required		Parts List
17mm Open Wrench	4mm Allen Wrench	1 #SP00460 License Plate Frame
13mm Open Wrench	Drill & 1/4" Drill Bit	2 #SP00217 #8 Washers
3mm Allen Wrench	Clippers	7 #SP00126 6m Nylock Nuts
T-20 Torx Wrench		4 #SP01080 6m Flat Washers
T-25 Torx Wrench		7 #SP00974 6m x 16m x 1.25 Allen Bolts
T-30 Torx Wrench		6 #SP00176 1/4" Flat Washers (Large)
T-45 Torx Wrench		2 6" Zip Ties

1. Start by removing the stock rear seat using the OEM key.

2. Remove the bolt on the stock front seat, using a T-30 torx wrench (*Figure 1*).

3. Remove the two back bolts on the handrails, then loosen the two front bolts on the handrails, using a T-30 torx wrench (*Figure 2*).

4. Remove the two bolts on the storage tray, using a T-25 torx wrench (*Figure 3*).

5. Remove storage tray by gently lifting up the handrail, then pull out (*Figure 4*).

6. Cut all zip ties holding the license plate wire on the frame (*Figure 5*).

7. Loosen the bolt on the belt guard to release the wire, then re-tighten (*Figure 6*).

8. Clip the zip tie on the wire cover (*Figure 7*).

9. Unhook the wire with wire cover from the clips (*Figure 8*).

10. Clip the zip ties from the wire cover, then separate the wiring from the wire cover to expose the license plate connector (*Figure 9*), then disconnect.

11. Weave wire and wire cover behind the sub-frame, then across to the other side (*Figure 10*).



FIG 1



FIG 2



FIG 3



FIG 4



FIG 5

12. Loosen bolt on the side cover, push wire with wire cover down (*Figure 11*), re-tighten bolt on side cover, then route the wire with wire cover under the subframe towards the tail section (*Figure 12*).

13. Clamp or zip tie the loose wiring neatly out of the way (*Figure 13*).

14. Remove the license plate bracket (*Figure 14*), using a 13mm open wrench and a T-45 torx wrench. Discard bolts.



15. Remove license plate, using a T-20 torx wrench.

16. Unsnap the cover on the license plate light (*Figure 15*).

17. Remove the three bolts on the license plate bracket to expose the screws to the license plate light (*Figure 16*).

18. Using a 3mm Allen wrench, remove the two bolts on the license plate light, then weave wire out (*Figure 17*).



19. Route the license plate light wire through the undertail kit and secure with the stock bolts and the supplied #8 washers (*Figure 18*). **DO NOT OVER TIGHTEN.**

20. Remove the bolts on the OEM luggage rack, using a T30 torx wrench (*Figure 19*). Remove the rack.



21. Place the supplied template on the molding marks on the inner splash guard (*Figure 20*), then drill four holes, using a 1/4" drill bit (*Figure 21*).

22. Install the Corbin undertail kit by routing the wires up through the middle hole on your splash guard (*Figure 22*), then secure the undertail kit with the supplied 6m Allen bolts and big flat washers through the top of the splash guard, then secure underneath with a big flat washer and nylock nut. (*Figure 23*), using a 4mm Allen wrench. Snug into place, but **DO NOT OVER TIGHTEN!** Over tightening may crack the undertail kit.



27. Reconnect the wiring to the license plate light.

28. Bundle wires and secure with the provided zip ties (*Figure 24*).

29. Reinstall the storage tray.

28. Install the license plate and supplied frame if desired, on to the undertail kit.





FIG 18



FIG 22



FIG 19



FIG 23



FIG 20



FIG 24



FIG 21

Questions? Give us a holler...  
**800-223-4332**  
tech@corbin.com